


90 20 70 057 06





handle

SERIES-VARIOUS

90 20 70 057 06

Spare parts list

No.	Item Number	Name	Quantity used	Delivery time
1	09 20 70 057-00	handle	3	10
2	09 31 11 007 90	pin	3	2
3	09 27 78 033-00	rosette	3	10
4	09 14 10 086 90	seal	3	2
5	90 12 12 223 00 90	fixing cap	3	2
6	09 23 30 074 90	nut	3	2
7	09 12 12 059 90	sleeve	3	2
8	09 30 30 167 90	screw	3	2
9	09 30 30 167 90	screw	2	2