



Product Features

- Handshower holder moves up and down, angle adjustable
- Knob with finger grip for easy slide adjustment

Available Finishes

Chrome	28631000
Brushed Nickel	28631820

Optional Accessories

Cassetta'S Puro Soap Dish	28679000
Cassetta'S Double Soap Dish	28675000

The measurements shown are for reference only.

Products and specifications shown are subject to change without notice.

Specification sheet revised 1/2008